



RELEASED
12/4/17

PPP

| | |
|-------------|------------|
| Part Number | K10003 |
| Description | Saddle Kit |

| | | | |
|-----------------|------|-----------|---------------|
| Box Part Number | BX21 | Dimension | 30.25 x 8 x 5 |
| | | | L x W x H |
| Other Packaging | N/A | Dimension | |
| Logo Decals | N/A | N/A | |

Packaging Instructions and Decal Placement

K10003

Place previously foamed saddles in box then add hardware and paperwork. Place some foam on the top to prevent hardware from moving. Seal box and apply label D2927-3 as per instructions in QSI 014 section 4.5.

NOTE: Fill all voids of box with foam to prevent movement.

D2729-1

D2729-3

N/A

| | |
|----------------------------|--|
| | Dart Aerospace Ltd. 1270 Aberdeen Street Hawkesbury, ON K6A 1K7 CANADA TEL.: 1 613 632-5200 |
| K10003 SADDLE KIT | |
| INCLUDES PARTS FOR: | |
| D205-634-011 | CHG010 |
| D205-634-015 | CHG009 |
| D205-634-111 | CHG003 |
| D204-635-011 | CHG010 |
| D204-635-111 | CHG002 |
| B/N: BXXXXX | |

Revision: L

Date: 12.02.23

H:\Admin-qa\iso\forms\PPP-1.Rev.A